

# Yamaha CS6x / CS6R / S80 / S30: Synthbank "Trance & Atmos"

## Loading Procedure

You can load voices with Type „all-voice“ from Smart Media Card to Internal Memory („INT“). But you can also load MIDI file to external sequencer and send it to CS6x / CS6R / S80 / S30. And you can send directly from editor. Important: INTERNAL Voices will be erased. Please save your own voices before loading!

You can recall Factory Voices with reset (Hold VOICE, PERFORM und STORE switching power on).

There are three ways to transmit voices to CS6x / CS6R / S80 / S30, if you don't load directly from Smart media Card:

1. Send File „Trance.S2V“ with CARD FILER from PC/MAC to Smart Media Card and load voices with „all-voice“.
2. Load file „Trance.S2V“ to PC-Editor and send voices directly to CS6x / CS6R / S80 / S30.
3. Load file Standard MIDI File „Trance.MID“ to external sequencer (Cubase, Logic, XG-works...) and start sequencer with slow tempo. CS6x / CS6R / S80 / S30 will receive voices.

## Soundoverview „Trance & Atmos“

007 Ld: Brass SAW	033 Ld: Loud Lead	065 Pd: Up/Down PD	097 Ld: TB Like
008 Ld: Broken LD	034 Ld: Lead Voice	066 Ld: Uuuuaahhhh	098 Ld: Access LK
003 Sq: Arp Line	035 Ld: Nice Lead	067 Ld: WatAnderes	099 Gt: Veloc. Gtr
004 Sq: Arp	036 Pd: Nice Pad	068 FX: Wind FX	100 Ld: Again C64
005 Sq: Arpeg.mich	037 Ld: Orcane LD	069 Ld: Wobble LD	101 Fx: Voice Down
006 Ba: Bass Voice	038 Or: Organe VC	070 Ld: YamahaCS6x	102 Ld: Voice Lead
007 BA: Arp Bass	039 Pd: Pad Voice	071 Ld: Ziiiiih LD	103 Fx: Voice Up
008 Sq: Arp Voice	040 Pd: Pad	072 Ld: P50-2 Lead	104 Ld: NovationLK
009 Ld: BrummBrumm	041 Ld: Phaser LD	073 Or: Shorty	105 Sq: DX7 Pad
010 Ld: C64 Arp	042 Ld: Pitched LD	074 Ld: Classical	106 Sq: SomeString
011 Ba: C64 Bass 3	043 Ld: Pures SAW	075 Pd: Gater Pad2	107 Pd: Ghost Pad
012 Ld: C64 Bass	044 Pd: SAW Pad	076 Se: VocoderLke	108 Et: Nice Flute
013 Ba: C64 Bass 2	045 Ld: Sounds C64	077 Ld: Bazuuka	109 Ba: Virus Like
014 Pf: C64	046 Sq: SAW Arp 03	078 Ba: Old Style	110 Fx: Pling FX
015 Ld: ClickClack	047 Ld: SAW die 1.	079 Ba: Old Style2	111 Ba: Vel. Slap
016 Pd: CS80 Pad	048 Ld: SAW die 2.	080 Or: DX7 Like	112 Ld: I Love C64
017 Pd: Dance PD	049 Ld: SAW die 3.	081 Pd: Vision Pad	113 Ld: Detuned
018 Se: Dance	050 Ld: SAW Dry	082 Pd: Long LFO	114 Pd: Sensitive
019 Dr: Dr Arp C3	051 Pd: SchwaebnLD	083 Ba: Agressive	115 Fx: Background
020 Dr: DR Snare A	052 Pd: Sea Pad	084 Se: Filter Cut	116 Ba: Schub Bass
021 Sc: Eiermann	053 Pd: Soft LD/PD	085 FX: Breaaaaak	117 Ba: DX7-2 Bass
022 Ld: Fall Herab	054 Pd: Soooooftig	086 Se: Vision Arp	118 Ba: DX7-2Bass2
023 Ld: FMD Lead	055 Ld: SqSa Voice	087 FX: Breaaaaak2	119 Pd: Wind Pad 2
024 Pd: Gater PD	056 Pd: Squeeze PD	088 Pd: Shinobi LD	120 Ld: Q Like
025 Ld: Hmmm...	057 Ba: Ssssuubbass	089 Ld: C64 4Ever	121 Ld: SAW Rulez
026 Or: Is CoolMan	058 Pd: String Pad	090 Ld: NothingSpl	122 Ld: AgainVirus
027 Ld: Jardin LD	059 Ba: Sweep BA 2	091 Br: LivinBrass	123 Pd: Virus Arp.
028 Fx: Kater Nervt	060 Ba: Sweep Bass	092 Or: DX7 Like 2	124 Pd: Vintage
029 Ld: KatzInSack	061 Ld: Sweep LD	093 Or: DX7 Like 3	125 Dr: T9HH1 / C3
030 Wv: Lame Arp	062 Pd: Sweep Pad	094 Ld: Krestology	126 Dr: T9HH2 / C3
031 Ld: Lame Lead	063 Ld: Sweep Peep	095 Sq: Krestolog2	127 Dr: T9Crash/C3
032 Ld: Lead Lead	064 Ba: Synth Bass	096 Or: DX7 Like 4	128 Dr: T9Clap/C3#



**Am Langberg 97 A**

**D-21033 Hamburg**

**Telefon: 040 - 738 62 23**

**E-Mail: [vertrieb@easysounds.de](mailto:vertrieb@easysounds.de)**

**[www.easysounds.de](http://www.easysounds.de)**