



MOTIF ES 6 / 7 / 8

MOTIF-RACK ES

MO6 / MO8

S90 ES

Voicebank
„Stage & Studio“

Produced by Peter Krischker, October 2006

featured by Yamaha Music Central Europe GmbH

<http://www.easysounds.de/>

vertrieb@easysounds.de

„Stage & Studio“

„Stage & Studio“ includes the most important standard instruments and synthsounds, which are useful for live-music, pop-productions and entertainment.

Playability and suitability of the voices was tested by several live-musicians and prepared for perfect live- and studio usability.

Most voices are new programmed. Some standard-instruments are optimized versions of preset-voices.

Some voices like string ensembles, brass sections or string/bell/synth-combinations include complex layer-sounds, which are found normally in performance mode. This allows very easy making of individual Live-performances by user.

Voices doesn't include user waveforms or samples.
Installation of optional DIMMs is not needed.

Overview of voice types:

- Keyboards (Acoustic Piano, Electric Piano)
- Bells
- Organ
- Bass
- Guitar
- Strings
- Brass
- Reed
- Synth Leads
- Synthpads
- Synth Comp

Loading voices to Motif ES

In folder „MOTIF_ES“ you find following files, which include same 128 Voices (User Voice Bank 1):

STAGE_ES.W7A (ALL-File)
STAGE_ES.W8A

STAGE_ES.W7V (AllVoice-File)
STAGE_ES.W8V

STAGE_ES.W7E (Voice Editor-File)
STAGE_ES.W8E

If you received set with download or CD-ROM you have to copy this files to Smart Media Card or USB-device before loading to MOTIF ES. If you have connected USB CD-ROM drive to MOTIF ES you can load files directly from CD-ROM.

With loading above listed **ALL-file** all user data of Motif ES will be overwritten (User Voices, Performances, Master, User Arpeggios, Songs, Pattern, Waveforms, Utility-Settings).

Please save your data before loading files.

You can recall Factory Voices with Factory Set (UTILITY JOB).

You can load single voices using File-Type „Voice“.

With loading above listed **AllVoice-file** only user voices will be overwritten.

New Voices will be loaded to Voice Bank USER1.

Alternately you can transmit the voicebank using the **Voice Editor** from computer (Windows-PC or Mac OS X) to MOTIF ES. Please load above listed Voice Editor-File to MOTIF ES Voice Editor.

The **AllSong-File** „**STAGE_PF**“ includes 3 additional Song-Mixing Live-Performances. They can be used independent of voicebank, because the used voices are stored as Song-Voices.

Loading voices to S90 ES

Voices can be loaded directly from USB-Device to S90 ES or transmitted with S90 ES Voice Editor.

In folder „S90_ES“ you find following files, which include same 128 Voices (User Voice Bank 1):

STAGE_90.W7V (AllVoice-File)
STAGE_90.W8V

STAGE_90.S7E (Voice Editor-File)

If you received set with DOWNLOAD or CD-ROM you have to copy above listed files to USB-device before loading to S90 ES. Then connect USB-Device with S90 ES and load set with FILE – LOAD – **Type AllVoice**.

With loading AllVoice-file user voices will be overwritten. Please save your data before loading files. You can recall Factory Voices with Factory Set (UTILITY JOB).

You can load single voices using **File-Type „Voice“**.

New Voices will be loaded to Voice Bank USER1.

Alternately you can transmit the voicebank using the **Voice Editor** from computer (Windows-PC or Mac OS X) to S90 ES. Please load above listed Voice Editor-File to S90 ES Voice Editor.

Loading voices to MO6 / MO8

Voices can be loaded directly from USB-Device to MO or transmitted with MO Voice Editor.

In folder „MO6_MO8“ you find following files, which include same 128 Voices (User Voice Bank 1):

STAGE_MO.W7V (AllVoice-File)

STAGE_MO.W8V

STAGE_MO.W7E (Voice Editor-File)

If you received set with DOWNLOAD or CD-ROM you have to copy above listed files to USB-device before loading to MO. Then connect USB-Device with MO and load set with FILE – LOAD – **Type AllVoice**.

With loading AllVoice-file user voices will be overwritten. Please save your data before loading files. You can recall Factory Voices with Factory Set (UTILITY JOB).

You can load single voices using **File-Type „Voice“**.

New Voices will be loaded to Voice Bank USER1.

Alternately you can transmit the voicebank using the **Voice Editor** from computer (Windows-PC or Mac OS X) to MO. Please load above listed Voice Editor-File to MO Voice Editor.

Loading Voices to MOTIF-RACK ES

Transmitting voices will be done using MOTIF-RACK ES Voice Editor. Voices of USER Voicebank will be overwritten. Please save your own voices before transmitting.

Factory Voices can be restored with Factory Set (UTILITY JOB).

Steps for transmitting voices:

1. Load MOTIF-RACK Voice Editor
2. Voice Editor Setup: Select MIDI OUT Port.
3. Load Voice Editor File "STAGE_MR.w9e" from folder „MOTIF-RACK ES“
4. Select „Setup – Transmit Voice Bulk – Normal User 1“.
5. Press START. New voices will be sent to User Voice Bank 1 now.
6. After displaying „Transmit completed successfully“ in editor please wait for disappearing „Receive MIDI bulk“ in MOTIF-RACK ES display.
7. After transmission you will still see the voice which was selected before. Only after selecting next voice you will see the new voices.

Overview: „Stage & Studio“ (User Voice Bank 1)

1	Pop Grand	Ap
2	AP&Strings	Ap
3	SoftStereo	Kb
4	Vintage Rh	Kb
5	DX Ballad	Kb
6	Dee Six	Kb
7	Strngbell1	Cp
8	Strngbell2	Cp
9	PopBells1	Cp
10	PopBells2	Cp
11	PopBells3	Cp
12	Wet Vibes	Cp
13	Full Organ	Or
14	Dark Organ	Or
15	First Bars	Or
16	Exeptional	Or
17	BrightRock	Or
18	All Crunch	Or
19	Little Pig	Or
20	ComboOrgan	Or
21	Housy	Or
22	ChorusOrgn	Or
23	Organ Pad	Or
24	Quetschn	Kb
25	Lambada	Kb
26	AccrdEnsemb	Kb
27	Harmonica	Rp
28	Spanish	Gt
29	NylonPad	Gt
30	Western	Gt
31	California	Gt
32	Clean Lead	Gt
33	PopChorus	Gt
34	Blusy	Gt
35	CrunchLead	Gt
36	Pick Bass	Ba
37	FingerBass	Ba
38	Superdark	Ba
39	Punch Bass	Ba
40	Rezzy	Ba
41	Attack	Ba
42	FatSquare	Ba
43	Synthpower	Ba

44	Disco Bass	Ba
45	FM Snapper	Ba
46	StrngOrch1	St
47	StrngOrch2	St
48	BigStrings	St
49	EnsembVelo	St
50	Symphonic	St
51	HybridStrg	St
52	ButterStrg	St
53	SynthEnsemb	St
54	Wide&Brite	St
55	Trumprtanz	Br
56	TrumpetVel	Br
57	TrumpetPic	Br
58	TrumpetMute	Br
59	Trombone	Br
60	Alto Sax	Rp
61	SweetAlto	Rp
62	SopranSax	Rp
63	Tenor Sax	Rp
64	BaritonSax	Rp
65	SforzaOctv	Br
66	StabOctav	Br
67	Big Brass	Br
68	FallsVelo1	Br
69	FallsVelo2	Br
70	StaccSect1	Br
71	StaccSect2	Br
72	FallsSect1	Br
73	FallsSect2	Br
74	PWM Swell	Br
75	PWM Fast	Br
76	JP Stereo	Br
77	Petit	Br
78	Wet Synth	Br
79	Jumper 1	Br
80	Jumper 2	Br
81	Wild PWM	Ld
82	Wild Saw	Ld
83	PercSquare	Ld
84	The Final	Ld
85	Mr. Fusion	Ld
86	SoftSquare	Ld

87	SoftSaw	Ld
88	101SubLead	Ld
89	TranceHook	Ld
90	Skandal!!!	Ld
91	LiquidAir	Sc
92	BalladComp	Sc
93	Pop Comp	Sc
94	HeavenBell	Sc
95	Mixed Comp	Sc
96	Saw Comp	Sc
97	BellComp1	Sc
98	BellComp2	Sc
99	Key Comp	Sc
100	Poly Dance	Sc
101	Faaat Comp	Sc
102	PowerComp	Sc
103	Venus Pad	Pd
104	Beauty Pad	Pd
105	Disco Pad	Pd
106	Phaser Pad	Pd
107	ThinThread	Pd
108	Dark Side	Pd
109	Sweet Vox	Pd
110	Digi Cream	Pd
111	DigiBright	Pd
112	Digi Dark	Pd
113	BriteSwell	Pd
114	Velo Swell	Pd
115	WarmSwell	Pd
116	Synthvox 1	Pd
117	Synthvox 2	Pd
118	Oooh Choir	Pd
119	Haah Choir	Pd
120	Ambient X	Me
121	Dreamer	Me
122	Addiction	Me
123	Moonlight	Me
124	PWWArp MW	Co
125	SawOctArp	Co
126	Company	Co
127	PopChrds1	Co
128	PopChrds2	Co